



LIMITED WARRANTY

BioSure Professional is a division of Biotek Environmental Science Ltd. ("BES"). BES warranties new equipment manufactured in BES's designated facilities to be free of defects due to poor materials or workmanship for the period of time listed below (following the date of original installation or purchase):

- 1 Year Parts Only Replacement (excluding spray head and battery)
- Pressurized Spray Head 6 months parts only
- Lithium Polymer Battery 6 months

Exclusions: Certain BES parts that are expendable by nature and that need to be replaced frequently may not be covered. BES is not liable under these warranties for repairs or damages due to improper operation, attempted repairs or installation by unauthorized persons, alterations, abuse, fire, flood, or acts of nature. Additionally, this warranty may be voided in the case of:

- Failure to follow BES (and BioSure Professional) instructions for use, care, or maintenance
- Removal, alteration, or defacing of the BES-affixed serial number and other labels Mechanical damage
- Use of fluids other than clean, potable water

This warranty is conditional upon BES receiving notice of any defect subject to this warranty within thirty (30) days of its original discovery by the Buyer. For service or warranty questions, contact the BES service department or BES authorized dealer nearby.

ATTENTION

- Do NOT use a power supply voltage other than being specified on the product.
 Do NOT plug or unplug the Power Cord if your hands are wet.
- BioSure Professional Ozone Spray Bottle is not a toy. Supervision is required when children present.
- Do not spray directly into the eyes.
- Dispose of properly.

This device is designed to generate ozone electrochemically in clean water, with the amount of ozone well below typical safety limits and regulations when used correctly. Ozone can be sensed by smell at a level as low as 0.02ppm. It is normal and expected to be able to detect a mild ozone smell from the open bottle mouth. However, ozone can be irritable if inhaled in instant large quantities. For safety, do NOT inhale the ozone gas produced by this device directly.

Thank you for purchasing BioSure Professional product. Please read this manual carefully and follow the instructions for using this product.

8

USB-C

Desiccant bag

BIOTEK ENVIRONMENTAL SCIENCE LTD. www.besgroups.com

Version 1.0



Professional Ozone Spray Bottle F0S7161-P

INSTRUCTIONS & REFERENCE GUIDE

CAUTION

- To reduce the risk of fire, do not expose the appliance to naked flame sources (for example, lighted candles).
- Do not expose the batteries (batteries installed) to excessive heat such as sunshine, fire or the like for a long time.
- Do not dismantle, open or shred batteries.
- In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.
- Batteries need to be charged before use. Always refer to the manufacturer's instructions or equipment manual for proper charging instructions.
- After extended period of storage, it may be necessary to charge and discharge the cells or batteries several times to obtain maximum performance.



 \bigcirc

When the USB plug is inserted in a wet condition, a short circuit occurs due to the liquid (tap water) attached to the main unit and charging cable or foreign matter, it may cause abnormal heat generation or malfunction.

Never insert USB plug when the main unit or charging cable is in wet condition.

PREPARATION

BE FAMILIAR WITH YOUR NEW PROFESSIONAL OZONE SPRAY BOTTLE.

CHARGE

standard outlet.

FILL

SPRAY NOZZLE/ PRESSURIZED SPRAY HEAD 40 WATER LEVEL WINDOW INDICATOR LIGHT ACTIVATION BUTTON



CLEAN • Rinse the inside of the spray bottle with clean water ONLY. (*NOT dishwasher safe)

CARE

- Wipe the bottle surface with a soft cotton, microfiber, or paper textile,
- If the tap water quality in your region is hard, it can cause scaling on the spray bottle. It there is scaling, fill the bottle with warm citric acid solution and then wait for 30 minutes. After descaling, pour out the citric acid solution and wash the bottle with clean water.

MAINTENANCE

To maintain consistent performance, follow these care instructions.

- Do NOT operate the bottle when it is empty or at low water level, this may damage the ozone generator.
- Clean and empty the bottle at the end of each day.
- Use only attachments and replacement parts sold or recommended by manufacturer. • Use citric acid for every 3 months or every 4 weeks (depends on usage and water quality).

STORAGE

- Empty water from the spray bottle.
- Spray out the remaining water in the sprayer tube.
- Remove the spray head.
- Wait for the bottle dry, and then fasten the head.
- Store the spray bottle at room temperature, avoid dust.

PRECAUTIONS

ON SAFETY

 Important information such as the model name and product serial number are located on the bottom exterior.

ON PLACEMENT

• Do not set the unit in an inclined position.

• Do not leave the unit in a place subject to high temperature, such as direct sunlight, near a heat source or under lighting equipment.

ON CLEANING

• Do not use detergent nor solvents such as alcohol, benzine, thinner, to clean the bottle exterior surface.

• Do not clean the unit in a dishwasher.

OTHERS

• Do not use or leave the unit in an extremely cold or hot environment (temperature outside the range of 5 - 35°C).

• Even if you do not intend to use the unit for a long time, charge the battery to its full capacity once every 6 months to maintain its performance.

How to care for the unit when wet:

If the unit gets wet on the surface, wipe off the moisture using a soft, dry clean cloth. Be sure to wipe off excess moisture after filling the unit. After using the unit, drain all the water and leave it at room temperature, dry it until no moisture remains. Do not put the unit in a dish dryer to dry.

System requirements for charging battery using USB-C:

Using a USB power supply capable of feeding in DC 5V 1A.

SPECIFICATIONS

OZONE TECHNOLOGY

Ozone generator: Built-in parallel plate electrodes electrolytic ozone generator Ozonated water concentrations: Up to 3.0ppm^{*1}

Hardness 180ppm as CaCO₃

Lithium polymer 3.7V 1000mAh DC 5V 1A (using the USB power supply)

*1Actual performance concentrations may vary from the listed data due to operating conditions.

WATER

Max. fill capacity: 150ml (5 oz.) 5-35°C (41-95°F) Water temperature:

Water quality requirements: Total Dissolved Solids (TDS) 60 - 200ppm;

BATTERY

Battery spec.: Charging power:

60 minutes approx. (first time charge 120min.) Charging time: Battery performance time:

Approx. 500hr in idle state; approx. 2.5hr in total for both modes 1&2 (collective time, including standby). If the mode 1 is repeated without standby the usage life will be approx.

50min.*2 *2Actual performance time may vary from the listed time due to usage

GENERAL

Room temperature: 5 - 40°C (41 - 104°F) Dimensions (including spray head):

> 53mm (2") dia. x 255mm (10") [H], approx. 310g (0.68lbs) including battery (empty bottle)

conditions.

Supplied accessory: USB Type-C cable (1), Spray head (1) [attached to the unit]

Designed by BES in Taiwan. Assembled in China. Design and specifications are subject to change without notice.

TROUBLESHOOTING

Problem	Possible Cause	Solution
5 sec RED LED ON after operation	Battery low	Recharge
No response after pressing the activation button	Battery empty	Recharge
	Bad battery	Contact service agent
RED LED not ON during recharging	Bad adaptor or loosen connection	Replace adaptor or reconnect the charger
	Bad battery	Contact service agent
Breathing BLUE/RED LED during standby	Ozone Generator near end of life (2%)	Contact service agent
Quick Blinking RED LED during activation ※Function suspended	Ozone Generator life finished	
Shorter operating time	Battery near end of life	Contact service agent
Less ozone performance	Water TDS low	Correct water source
	Generator scaled	Clean bottle with citric acid solution
Blinking RED/GREEN LED during activation ※Function suspended	TDS too high (>200ppm)	Correct water source
Blinking RED/BLUE LED during activation ※Function suspended	TDS too low (<60ppm)	Correct water source
	Generator is heavily scaled	Clean bottle with citric acid solution
	Lack of water	Fill water



If the spray bottle does not operate when activation

button is pressed or a red light is ON after operation. The spray bottle needs to be recharged.

• Find the charging port on the back of the bottle.

• Fill the bottle with cold tap water ONLY.

Recommended water quality:

• Connect the charging cable (USB-C, included) to the device. • Connect the charging cable to an adaptor (output: DC 5V/1A) and plug them into a

• A breathing RED LED light indicates charging is taking place.

• Charging is complete when the indicator turns to be steady green.

It is NOT recommended to charge and operate the unit at the same time.

• Turn spray head on top counterclockwise and remove it from the bottle.

Clean or filtered water, TDS 60-200 ppm, Hardness < 180 ppm as CaCO₃.

Reattach the spray head to the bottle and turn clockwise to fasten it tightly.

Do NOT submerge under water. Do NOT add chemicals or soap. Use tap water ONLY.